

A division of Troy Sheet Metal Works, Inc. 1024 South Vail Avenue, Montebello, CA 90640 www.troyproducts.com 800 700-8769

Part No: AC-CHV19-RWS Vehicle: 1500 Silverado

Description: Rear window screen Model year: 2019



I.) Remove OEM trim:


- 1.) Remove upper "C" pillar plastic covers on both sides of vehicle.
- 2.) Remove (3) head rests.

II.) Install window screen:

3.) Place window screen on top of the window ledge with bottom flanges facing toward front of vehicle.



- 4.) Install (3) short angle brackets behind headliner and fasten to the top of the window screen using (6) provided washers and 1/4-20 acorn nuts. Do not tighten at this time.
 - a. Note: Some configurations come with PEM nuts instead of studs. These brackets should be assembled behind screen instead of in front of it using provided 1/4-20 x 1/2" button head screws and washers.



- 5.) Install (2) long angle brackets in lower corners of the window screen behind vehicle wiring and fasten to the window screen using (4) provided washers and ¼-20 acorn nuts. Do not tighten at this time.
- 6.) Install (2) medium length angle brackets above the previously installed angle brackets and fasten to the window screen using (4) provided washers and ½-20 acorn nuts. Do not tighten at this time.
- 7.) Using the angle bracket holes as a guide, drill (11) 3/16" holes into the vehicle sheet metal. Be careful to not drill into any wiring or sensors.
- 8.) Attach the brackets to the vehicle using (11) provided pop rivets.

III.) Install O.E.M. trim:

- 9.) Install upper plastic trim on both sides of vehicle.
- 10.) Install (3) headrests.
- 11.) Confirm seatbelts function properly.

Your installation is now complete. If you have any questions or suggestions for adding additional instructions, please call **Customer Service at (800) 700-8769.**

