



TROY PRODUCTS

INSTALLATION INSTRUCTIONS

June 23, 2011

Revision 0

A division of Troy Sheet Metal Works, Inc.
1024 South Vail Avenue, Montebello, CA 90640
www.troyproducts.com 800 700-8769

Part No: AC-DG2500-DS & PS
Description: Window guard

Vehicle: Dodge Ram 2500
Model year: 2008 - 2010



I.) Remove O.E.M. trim:

- 1.) Remove plastic trim on rear edge of window.



II.) Install window guard:

- 2.) Place window guard on top of rubber gasket and center in the opening.
- 3.) Using the existing holes in the guard as a template, drill (11) 3/16" holes into door frame.
- 4.) Fasten the guard to the door using the included 3/16" dia. pop rivets.



- 5.) Repeat above steps on opposite side of vehicle.

Your installation is now complete. If you have any questions or suggestions for adding additional instructions, please call **Customer Service at (800) 700-8769.**