

A division of Troy Sheet Metal Works, Inc. 1024 South Vail Avenue, Montebello, CA 90640 www.troyproducts.com 800 700-8769

Part No: AC-DUR18-HATCH Vehicle: Dodge Durango

Description: Cargo window screen Model year: 2018



## I.) Remove O.E.M. trim:

1.) Remove lift gate upper plastic trim.



## II.) Install window screen:

3.) Place the (2) upper lift gate window screen tabs into the window area and press the tabs against the door frame.



4.) Center the window screen.

- 5.) Insure the lower tabs and side tabs contact the door frame. Insure the window guard is centered on the window.
- 6.) Using the window screen as a template, carefully drill (6) 3/16" holes (through existing holes in the mounting tabs) into the vehicle frame. Drill through one layer of sheet metal only. Be cautious to not drill through any wires or mechanical devices in the door.
- 7.) Secure the window screen using (6) included pop rivets beginning at the top, followed by the sides.

## III.) Re-install O.E.M. trim:

8.) Re-install the plastic trim.

Your installation is now complete. If you have any questions or suggestions for adding additional instructions, please call **Customer Service at (800) 700-8769.** 

