



TROY PRODUCTS

INSTALLATION INSTRUCTIONS

May 19, 2016

Revision 0

*A division of Troy Sheet Metal Works, Inc.
1024 South Vail Avenue, Montebello, CA 90640
www.troyproducts.com 800 700-8769*

Part No: AC-FHDFB
Description: File box

Vehicle: All
Model year: All

I.) Install Floor plate:

- 1.) Install the vehicle specific floor plate (if equipped).
- 2.) Install console (if equipped).

II.) Install file lock box:

- 3.) Install (2) 3/8-16 carriage bolts through slots in floor of file box (bolt facing up) and loosely attach nuts on the bolts inside the lock box.
- 4.) Insert carriage bolt heads through keyhole slots in floor plate.
- 5.) Place file box onto floor plate and position as desired.
- 6.) File box can be attached to console with (2) 1/4-20 bolts. (If equipped)
- 7.) Securely tighten all fasteners.

Your installation is now complete. If you have any questions or suggestions for adding additional instructions, please call **Customer Service at (800) 700-8769.**

