



TROY PRODUCTS

INSTALLATION INSTRUCTIONS

Apr 4, 2019

Revision 0

A division of Troy Sheet Metal Works, Inc.
1024 South Vail Avenue, Montebello, CA 90640
www.troyproducts.com 800 700-8769

Part No: AC-SB-CHV19-MNT
Description: Rear seat mounting brackets

Vehicle: Silverado 1500
Model year: 2019



I.) Tip-up rear seats:

II.) Install brackets:

- 1.) Loosen rear seat mounting bolt using 18mm socket.



- 2.) Install bracket between washer and rear seat frame.
3.) Repeat steps 1,2 on opposite side of vehicle.
4.) Position the (2) brackets so they are parallel and the oval holes are 48.75\" apart center to center.
5.) Brackets can be bolted down through vehicle floor if desired.
6.) Tighten (2) seat bolts to OEM specifications.



Your installation is now complete. If you have any questions or suggestions for adding additional instructions, please call
Customer Service at (800) 700-8769.

AC-SB-CHV19-MNT

