



TROY PRODUCTS

INSTALLATION INSTRUCTIONS

Apr 3, 2019

Revision 0

A division of Troy Sheet Metal Works, Inc.
1024 South Vail Avenue, Montebello, CA 90640
www.troyproducts.com 800 700-8769

Part No: DP-DUR18-SET
Description: Door panels

Vehicle: Durango
Model year: 2018

I.) Remove O.E.M. door panel:

- 1.) After moving fasteners, pull up on door panel and separate from door.
- 2.) Disconnect all cables and connectors.
- 3.) Remove door panel.

II.) Install door panel:

- 4.) Place door panel flange into window opening and center in the window opening.



- 5.) Drill (11) 3/16" holes into door frame using the holes in the door panel as a template. Use caution when drilling to avoid drilling into door components.
- 6.) Attach the door panel to the door frame using (11) provided 3/16" pop rivets.
- 7.) Repeat above procedure for opposite side of vehicle.

Your installation is now complete. If you have any questions or suggestions for adding additional instructions, please call **Customer Service at (800) 700-8769**.

