

A division of Troy Sheet Metal Works, Inc. 1024 South Vail Avenue, Montebello, CA 90640 www.troyproducts.com 800 700-8769

Part No: DP-EXP18-SET Vehicle: Ford Expedition

Description: Door panels Model year: 2018



## I.) Remove O.E.M. door panel:

• Remove plastic cover plate by prying away from door, exposing fasteners.

• Remove (2) fasteners attaching door panel to door.



• Remove screw in bottom of door panel.




• Pull up on door panel and separate from door.

- Disconnect door handle cable.
- Disconnect electrical connector.
- Disconnect door lock cable.
- Remove door panel.

## II.) Install door panel:

Place door panel flange into window opening and center in the window opening.




## III.) INSTALL GAP PANEL

- Place gap panel over the door panel, assuring all mounting holes align including the door locking mechanism.
- Once all mounting holes align, drill the first hole across the door's locking mechanism. Use the first mounting hole as a guide for the rest of the 3/16" holes.



Begin drilling to insert 1 pop rivet at a time, this will allow the material to displace evenly assuring
a proper fitment. Drill/ insert one pop rivet at a time in a synchrionized pattern, one above the
first "guide" pop rivet following one in the bottom.



- \*\*Use caution when drilling to avoid drilling into door components\*\*
- Repeat above procedure for opposite side of vehicle.

Your installation is now complete. If you have any questions or suggestions for adding additional instructions, please call **Customer Service at (800) 700-8769.** 

