



TROY PRODUCTS

INSTALLATION INSTRUCTIONS

Mar 5, 2015
Revision 0

A division of Troy Sheet Metal Works, Inc.
1024 South Vail Avenue, Montebello, CA 90640
www.troyproducts.com 800 700-8769

Part No: KP-F150-15-SS
Description: Kick panels

Vehicle: Ford F-150
Model year: 2015



I.) Install Troy Products front partition:

II.) Install side kick panels:

- 1.) Move both front seats fully forward and tilt seat backs forward.
- 2.) Install driver side panel from front seat side of the partition. The (3) studs face toward the front of the vehicle and are oriented toward the center of the vehicle.



- 3.) Loosely attach the kick panel to the partition using (2) provided ¼-20 x 5/8" bolts, washers and nuts. Do not tighten at this time. Button head bolts should be on rear seat side of partition.
- 4.) Repeat steps 2-3 on opposite side of vehicle.

III.) Install center kick panel:

- 5.) From front seat side of the partition, install center kick panel over studs of the two side panels.



- 6.) Install (6) washers and ¼-20 nuts onto studs. Do not tighten at this time.

- 7.) Loosely attach the center panel to the partition using (2) provided ¼-20 x 5/8" bolts, washers and nuts. Do not tighten at this time. Button head bolts should be on rear seat side of partition.
- 8.) While applying downward pressure on the panels, securely tighten all fasteners.

Below is what the completed installation will look like.



Your installation is now complete. If you have any questions or suggestions for adding additional instructions, please call **Customer Service at (800) 700-8769**.

