

A division of Troy Sheet Metal Works, Inc.
1024 South Vail Avenue, Montebello, CA 90640
www.troyproducts.com 800 700-8769

Part No: PM-21TH
Description: Partition Mounting Kit

Vehicle: Chevrolet Tahoe
Model year: 2021




Tools Required

5/32 allen key	7/16 socket	Body panel removal tools
3/16 allen key	9/16 socket	
T55 driver	7mm socket	
	10mm socket	

Troy Products recommends reading through all installation instructions prior to installation to check for all necessary parts. To comply with manufacturer's safety ratings, all OEM self-threading bolts must be discarded and re-tightened with unused bolts to manufacturer's torque specifications.


I.) Preparation:

- 1.) Remove driver and passenger rear outer seat mount screws from front seats using a T55 driver.




- 2.) Remove driver and passenger "airbag" plastic cap from upper B-pillar trim using body panel removal tool or flat blade screwdriver. Remove screws behind panel using 7mm socket.

PRY FROM
TOP OF
PANEL




- 3.) Separate driver and passenger upper and lower B-pillar trim panels by prying lower trim outward at seam. Mounting pin locations are marked below. Side shown is driver side. Fully detach the upper trim from the B-pillar and set it aside.

MOUNTING
POINTS FROM
LOWER TO
UPPER PANEL





UPPER PANEL
MOUNTING
POINTS TO B
PILLAR

- 4.) With top trim removed, B-pillar handles are exposed. Remove both driver and passenger handles by unscrewing OEM M6 fasteners using 10mm socket. Handles will not be needed for the rest of the installation.







- 5.) Mount B-pillar brackets (#dbpb, #pbpb) to B-pillars where handles were mounted using original M6 mounting hardware removed in step 4. Replace trim and re-insert screws removed in step 2 using 7mm socket. Bracket is shown installed on driver side.




II.) Partition Installation:

- 6.) Place foot brackets (#fbp, #fbd) under seat rails where screws were previously removed. Insert tube spacers (2-SAB-FS-075) and rubber caps (2-PAR-23-04004) as shown. Insert fasteners into seat mounts holes but leave them loose.




- 7.) Insert partition (part number begins with TP-E, differs depending on configuration) into vehicle through rear doors and set on floor. Lift partition, tilt top of partition toward rear of vehicle, and slide partition tube onto mounting feet. Insert two 3/8-16x1 screws into B-pillar brackets as shown to hold partition in place. Tabs on partition tube sit outboard of pillar brackets. Lower partition tabs are not used.



INSERT SCREWS LOOSELY
ON BOTH DRIVER AND
PASSENGER SIDE

- 8.) Place upper wings (#uwkp, #uwkd) onto partition as shown and fasten with four ¼-20x0.875 screws, washers, and nylon nuts, two sets per wing. Ensure 3/8 screw passes through, in order of outboard to inboard, partition tab, B-pillar bracket, and polycarbonate wing. Outside of 3/8 bolt, toward head, should have a washer.


¼ FASTENERS



3/8 NUT THIS
SIDE, WASHER
ON OUTSIDE

- 9.) Tighten seat mount screws and 3/8 bolts.


- 10.) Position lower wings (#lwd, #lwp) on partition and kick panel as shown. Fasten in place with six ¼-20x0.625 screws two ¼-20x0.750 screws with 10 washers and 8 nylon nuts. Due to placement of partition tubes, nylon nuts are most easily held in place with an open end wrench.



- 11.) Ensure all fasteners are tight. If kick panels are to be installed, follow instructions for KP-21TH-SS next.

Your installation is now complete. If you have any questions or suggestions for adding additional instructions, please call **Customer Service at (800) 700-8769**.

REVISIONS			
ZONE	REV.	DESCRIPTION	DATE
	A	7.500 spacer was 6.375	11/27/2020
	B	New upper and lower wings, B Pillar bkt	11/29/2020
	C	Updated Lower Wings	9/9/2025
			DV



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	PM-21TH-#fbd	Driver Side Foot bracket	1
2	PM-21TH-#fbp	Passenger Side Foot Bracket	1
3	PM-21TH-#uwkd	Driver Upper wing kit	1
4	PM-21TH-#uwkp	Passenger Upper Wing kit	1
5	PM-21TH-#dbpb	Driver B Pillar Bracket	1
6	PM-21TH-#pbpb	Passenger B Pillar Bracket	1
7	PM-21TH-#lwd	Driver Lower Wing	1
8	PM-21TH-#lwp	Passenger Lower Wing	1
9	2-SAB-FS-075	Partition spacer 7.5"	2
10	PM-21TH-#hw	Loose Hardware	1
11	HW-SAB-PART14	Partition Mount Hardware Pack	1
12	3-PAK-331306	Box 33" L x 13" W x 6-3/8" H - DW	1






SHR 1024 South Vail Avenue Montebello, CA 90640-6020		DATE: 10/15/20 DRAWN: [blank] CHECKED BY: [blank] END APP: [blank] MFG APP: [blank] O.P.A.: [blank] COMMENTS: [blank]
TITLE: 2021 Tahoe Partition Mount		SIZE: DWG. NO. B PM-21TH
SCALE: 1:10		SHEET 1 OF 1

UNLESS OTHERWISE SPECIFIED:
 DIMS IN INCHES
 SURFACES: [blank]
 FINISH: [blank]
 DIMS IN INCHES: 1/8" > 1/4" > 3/8" > 1/2" > 5/8" > 3/4" > 1" > 1 1/4" > 1 1/2" > 1 3/4" > 2" > 2 1/4" > 2 1/2" > 2 3/4" > 3" > 3 1/4" > 3 1/2" > 3 3/4" > 4" > 4 1/4" > 4 1/2" > 4 3/4" > 5" > 5 1/4" > 5 1/2" > 5 3/4" > 6" > 6 1/4" > 6 1/2" > 6 3/4" > 7" > 7 1/4" > 7 1/2" > 7 3/4" > 8" > 8 1/4" > 8 1/2" > 8 3/4" > 9" > 9 1/4" > 9 1/2" > 9 3/4" > 10" > 10 1/4" > 10 1/2" > 10 3/4" > 11" > 11 1/4" > 11 1/2" > 11 3/4" > 12" > 12 1/4" > 12 1/2" > 12 3/4" > 13" > 13 1/4" > 13 1/2" > 13 3/4" > 14" > 14 1/4" > 14 1/2" > 14 3/4" > 15" > 15 1/4" > 15 1/2" > 15 3/4" > 16" > 16 1/4" > 16 1/2" > 16 3/4" > 17" > 17 1/4" > 17 1/2" > 17 3/4" > 18" > 18 1/4" > 18 1/2" > 18 3/4" > 19" > 19 1/4" > 19 1/2" > 19 3/4" > 20" > 20 1/4" > 20 1/2" > 20 3/4" > 21" > 21 1/4" > 21 1/2" > 21 3/4" > 22" > 22 1/4" > 22 1/2" > 22 3/4" > 23" > 23 1/4" > 23 1/2" > 23 3/4" > 24" > 24 1/4" > 24 1/2" > 24 3/4" > 25" > 25 1/4" > 25 1/2" > 25 3/4" > 26" > 26 1/4" > 26 1/2" > 26 3/4" > 27" > 27 1/4" > 27 1/2" > 27 3/4" > 28" > 28 1/4" > 28 1/2" > 28 3/4" > 29" > 29 1/4" > 29 1/2" > 29 3/4" > 30" > 30 1/4" > 30 1/2" > 30 3/4" > 31" > 31 1/4" > 31 1/2" > 31 3/4" > 32" > 32 1/4" > 32 1/2" > 32 3/4" > 33" > 33 1/4" > 33 1/2" > 33 3/4" > 34" > 34 1/4" > 34 1/2" > 34 3/4" > 35" > 35 1/4" > 35 1/2" > 35 3/4" > 36" > 36 1/4" > 36 1/2" > 36 3/4" > 37" > 37 1/4" > 37 1/2" > 37 3/4" > 38" > 38 1/4" > 38 1/2" > 38 3/4" > 39" > 39 1/4" > 39 1/2" > 39 3/4" > 40" > 40 1/4" > 40 1/2" > 40 3/4" > 41" > 41 1/4" > 41 1/2" > 41 3/4" > 42" > 42 1/4" > 42 1/2" > 42 3/4" > 43" > 43 1/4" > 43 1/2" > 43 3/4" > 44" > 44 1/4" > 44 1/2" > 44 3/4" > 45" > 45 1/4" > 45 1/2" > 45 3/4" > 46" > 46 1/4" > 46 1/2" > 46 3/4" > 47" > 47 1/4" > 47 1/2" > 47 3/4" > 48" > 48 1/4" > 48 1/2" > 48 3/4" > 49" > 49 1/4" > 49 1/2" > 49 3/4" > 50" > 50 1/4" > 50 1/2" > 50 3/4" > 51" > 51 1/4" > 51 1/2" > 51 3/4" > 52" > 52 1/4" > 52 1/2" > 52 3/4" > 53" > 53 1/4" > 53 1/2" > 53 3/4" > 54" > 54 1/4" > 54 1/2" > 54 3/4" > 55" > 55 1/4" > 55 1/2" > 55 3/4" > 56" > 56 1/4" > 56 1/2" > 56 3/4" > 57" > 57 1/4" > 57 1/2" > 57 3/4" > 58" > 58 1/4" > 58 1/2" > 58 3/4" > 59" > 59 1/4" > 59 1/2" > 59 3/4" > 60" > 60 1/4" > 60 1/2" > 60 3/4" > 61" > 61 1/4" > 61 1/2" > 61 3/4" > 62" > 62 1/4" > 62 1/2" > 62 3/4" > 63" > 63 1/4" > 63 1/2" > 63 3/4" > 64" > 64 1/4" > 64 1/2" > 64 3/4" > 65" > 65 1/4" > 65 1/2" > 65 3/4" > 66" > 66 1/4" > 66 1/2" > 66 3/4" > 67" > 67 1/4" > 67 1/2" > 67 3/4" > 68" > 68 1/4" > 68 1/2" > 68 3/4" > 69" > 69 1/4" > 69 1/2" > 69 3/4" > 70" > 70 1/4" > 70 1/2" > 70 3/4" > 71" > 71 1/4" > 71 1/2" > 71 3/4" > 72" > 72 1/4" > 72 1/2" > 72 3/4" > 73" > 73 1/4" > 73 1/2" > 73 3/4" > 74" > 74 1/4" > 74 1/2" > 74 3/4" > 75" > 75 1/4" > 75 1/2" > 75 3/4" > 76" > 76 1/4" > 76 1/2" > 76 3/4" > 77" > 77 1/4" > 77 1/2" > 77 3/4" > 78" > 78 1/4" > 78 1/2" > 78 3/4" > 79" > 79 1/4" > 79 1/2" > 79 3/4" > 80" > 80 1/4" > 80 1/2" > 80 3/4" > 81" > 81 1/4" > 81 1/2" > 81 3/4" > 82" > 82 1/4" > 82 1/2" > 82 3/4" > 83" > 83 1/4" > 83 1/2" > 83 3/4" > 84" > 84 1/4" > 84 1/2" > 84 3/4" > 85" > 85 1/4" > 85 1/2" > 85 3/4" > 86" > 86 1/4" > 86 1/2" > 86 3/4" > 87" > 87 1/4" > 87 1/2" > 87 3/4" > 88" > 88 1/4" > 88 1/2" > 88 3/4" > 89" > 89 1/4" > 89 1/2" > 89 3/4" > 90" > 90 1/4" > 90 1/2" > 90 3/4" > 91" > 91 1/4" > 91 1/2" > 91 3/4" > 92" > 92 1/4" > 92 1/2" > 92 3/4" > 93" > 93 1/4" > 93 1/2" > 93 3/4" > 94" > 94 1/4" > 94 1/2" > 94 3/4" > 95" > 95 1/4" > 95 1/2" > 95 3/4" > 96" > 96 1/4" > 96 1/2" > 96 3/4" > 97" > 97 1/4" > 97 1/2" > 97 3/4" > 98" > 98 1/4" > 98 1/2" > 98 3/4" > 99" > 99 1/4" > 99 1/2" > 99 3/4" > 100" > 100 1/4" > 100 1/2" > 100 3/4" > 101" > 101 1/4" > 101 1/2" > 101 3/4" > 102" > 102 1/4" > 102 1/2" > 102 3/4" > 103" > 103 1/4" > 103 1/2" > 103 3/4" > 104" > 104 1/4" > 104 1/2" > 104 3/4" > 105" > 105 1/4" > 105 1/2" > 105 3/4" > 106" > 106 1/4" > 106 1/2" > 106 3/4" > 107" > 107 1/4" > 107 1/2" > 107 3/4" > 108" > 108 1/4" > 108 1/2" > 108 3/4" > 109" > 109 1/4" > 109 1/2" > 109 3/4" > 110" > 110 1/4" > 110 1/2" > 110 3/4" > 111" > 111 1/4" > 111 1/2" > 111 3/4" > 112" > 112 1/4" > 112 1/2" > 112 3/4" > 113" > 113 1/4" > 113 1/2" > 113 3/4" > 114" > 114 1/4" > 114 1/2" > 114 3/4" > 115" > 115 1/4" > 115 1/2" > 115 3/4" > 116" > 116 1/4" > 116 1/2" > 116 3/4" > 117" > 117 1/4" > 117 1/2" > 117 3/4" > 118" > 118 1/4" > 118 1/2" > 118 3/4" > 119" > 119 1/4" > 119 1/2" > 119 3/4" > 120" > 120 1/4" > 120 1/2" > 120 3/4" > 121" > 121 1/4" > 121 1/2" > 121 3/4" > 122" > 122 1/4" > 122 1/2" > 122 3/4" > 123" > 123 1/4" > 123 1/2" > 123 3/4" > 124" > 124 1/4" > 124 1/2" > 124 3/4" > 125" > 125 1/4" > 125 1/2" > 125 3/4" > 126" > 126 1/4" > 126 1/2" > 126 3/4" > 127" > 127 1/4" > 127 1/2" > 127 3/4" > 128" > 128 1/4" > 128 1/2" > 128 3/4" > 129" > 129 1/4" > 129 1/2" > 129 3/4" > 130" > 130 1/4" > 130 1/2" > 130 3/4" > 131" > 131 1/4" > 131 1/2" > 131 3/4" > 132" > 132 1/4" > 132 1/2" > 132 3/4" > 133" > 133 1/4" > 133 1/2" > 133 3/4" > 134" > 134 1/4" > 134 1/2" > 134 3/4" > 135" > 135 1/4" > 135 1/2" > 135 3/4" > 136" > 136 1/4" > 136 1/2" > 136 3/4" > 137" > 137 1/4" > 137 1/2" > 137 3/4" > 138" > 138 1/4" > 138 1/2" > 138 3/4" > 139" > 139 1/4" > 139 1/2" > 139 3/4" > 140" > 140 1/4" > 140 1/2" > 140 3/4" > 141" > 141 1/4" > 141 1/2" > 141 3/4" > 142" > 142 1/4" > 142 1/2" > 142 3/4" > 143" > 143 1/4" > 143 1/2" > 143 3/4" > 144" > 144 1/4" > 144 1/2" > 144 3/4" > 145" > 145 1/4" > 145 1/2" > 145 3/4" > 146" > 146 1/4" > 146 1/2" > 146 3/4" > 147" > 147 1/4" > 147 1/2" > 147 3/4" > 148" > 148 1/4" > 148 1/2" > 148 3/4" > 149" > 149 1/4" > 149 1/2" > 149 3/4" > 150" > 150 1/4" > 150 1/2" > 150 3/4" > 151" > 151 1/4" > 151 1/2" > 151 3/4" > 152" > 152 1/4" > 152 1/2" > 152 3/4" > 153" > 153 1/4" > 153 1/2" > 153 3/4" > 154" > 154 1/4" > 154 1/2" > 154 3/4" > 155" > 155 1/4" > 155 1/2" > 155 3/4" > 156" > 156 1/4" > 156 1/2" > 156 3/4" > 157" > 157 1/4" > 157 1/2" > 157 3/4" > 158" > 158 1/4" > 158 1/2" > 158 3/4" > 159" > 159 1/4" > 159 1/2" > 159 3/4" > 160" > 160 1/4" > 160 1/2" > 160 3/4" > 161" > 161 1/4" > 161 1/2" > 161 3/4" > 162" > 162 1/4" > 162 1/2" > 162 3/4" > 163" > 163 1/4" > 163 1/2" > 163 3/4" > 164" > 164 1/4" > 164 1/2" > 164 3/4" > 165" > 165 1/4" > 165 1/2" > 165 3/4" > 166" > 166 1/4" > 166 1/2" > 166 3/4" > 167" > 167 1/4" > 167 1/2" > 167 3/4" > 168" > 168 1/4" > 168 1/2" > 168 3/4" > 169" > 169 1/4" > 169 1/2" > 169 3/4" > 170" > 170 1/4" > 170 1/2" > 170 3/4" > 171" > 171 1/4" > 171 1/2" > 171 3/4" > 172" > 172 1/4" > 172 1/2" > 172 3/4" > 173" > 173 1/4" > 173 1/2" > 173 3/4" > 174" > 174 1/4" > 174 1/2" > 174 3/4" > 175" > 175 1/4" > 175 1/2" > 175 3/4" > 176" > 176 1/4" > 176 1/2" > 176 3/4" > 177" > 177 1/4" > 177 1/2" > 177 3/4" > 178" > 178 1/4" > 178 1/2" > 178 3/4" > 179" > 179 1/4" > 179 1/2" > 179 3/4" > 180" > 180 1/4" > 180 1/2" > 180 3/4" > 181" > 181 1/4" > 181 1/2" > 181 3/4" > 182" > 182 1/4" > 182 1/2" > 182 3/4" > 183" > 183 1/4" > 183 1/2" > 183 3/4" > 184" > 184 1/4" > 184 1/2" > 184 3/4" > 185" > 185 1/4" > 185 1/2" > 185 3/4" > 186" > 186 1/4" > 186 1/2" > 186 3/4" > 187" > 187 1/4" > 187 1/2" > 187 3/4" > 188" > 188 1/4" > 188 1/2" > 188 3/4" > 189" > 189 1/4" > 189 1/2" > 189 3/4" > 190" > 190 1/4" > 190 1/2" > 190 3/4" > 191" > 191 1/4" > 191 1/2" > 191 3/4" > 192" > 192 1/4" > 192 1/2" > 192 3/4" > 193" > 193 1/4" > 193 1/2" > 193 3/4" > 194" > 194 1/4" > 194 1/2" > 194 3/4" > 195" > 195 1/4" > 195 1/2" > 195 3/4" > 196" > 196 1/4" > 196 1/2" > 196 3/4" > 197" > 197 1/4" > 197 1/2" > 197 3/4" > 198" > 198 1/4" > 198 1/2" > 198 3/4" > 199" > 199 1/4" > 199 1/2" > 199 3/4" > 200" > 200 1/4" > 200 1/2" > 200 3/4" > 201" > 201 1/4" > 201 1/2" > 201 3/4" > 202" > 202 1/4" > 202 1/2" > 202 3/4" > 203" > 203 1/4" > 203 1/2" > 203 3/4" > 204" > 204 1/4" > 204 1/2" > 204 3/4" > 205" > 205 1/4" > 205 1/2" > 205 3/4" > 206" > 206 1/4" > 206 1/2" > 206 3/4" > 207" > 207 1/4" > 207 1/2" > 207 3/4" > 208" > 208 1/4" > 208 1/2" > 208 3/4" > 209" > 209 1/4" > 209 1/2" > 209 3/4" > 210" > 210 1/4" > 210 1/2" > 210 3/4" > 211" > 211 1/4" > 211 1/2" > 211 3/4" > 212" > 212 1/4" > 212 1/2" > 212 3/4" > 213" > 213 1/4" > 213 1/2" > 213 3/4" > 214" > 214 1/4" > 214 1/2" > 214 3/4" > 215" > 215 1/4" > 215 1/2" > 215 3/4" > 216" > 216 1/4" > 216 1/2" > 216 3/4" > 217" > 217 1/4" > 217 1/2" > 217 3/4" > 218" > 218 1/4" > 218 1/2" > 218 3/4" > 219" > 219 1/4" > 219 1/2" > 219 3/4" > 220" > 220 1/4" > 220 1/2" > 220 3/4" > 221" > 221 1/4" > 221 1/2" > 221 3/4" > 222" > 222 1/4" > 222 1/2" > 222 3/4" > 223" > 223 1/4" > 223 1/2" > 223 3/4" > 224" > 224 1/4" > 224 1/2" > 224 3/4" > 225" > 225 1/4" > 225 1/2" > 225 3/4" > 226" > 226 1/4" > 226 1/2" > 226 3/4" > 227" > 227 1/4" > 227 1/2" > 227 3/4" > 228" > 228 1/4" > 228 1/2" > 228 3/4" > 229" > 229 1/4" > 229 1/2" > 229 3/4" > 230" > 230 1/4" > 230 1/2" > 230 3/4" > 231" > 231 1/4" > 231 1/2" > 231 3/4" > 232" > 232 1/4" > 232 1/2" > 232 3/4" > 233" > 233 1/4" > 233 1/2" > 233 3/4" > 234" > 234 1/4" > 234 1/2" > 234 3/4" > 235" > 235 1/4" > 235 1/2" > 235 3/4" > 236" > 236 1/4" > 236 1/2" > 236 3/4" > 237" > 237 1/4" > 237 1/2" > 237 3/4" > 238" > 238 1/4" > 238 1/2" > 238 3/4" > 239" > 239 1/4" > 239 1/2" > 239 3/4" > 240" > 240 1/4" > 240 1/2" > 240 3/4" > 241" > 241 1/4" > 241 1/2" > 241 3/4" > 242" > 242 1/4" > 242 1/2" > 242 3/4" > 243" > 243 1/4" > 243 1/2" > 243 3/4" > 244" > 244 1/4" > 244 1/2" > 244 3/4" > 245" > 245 1/4" > 245 1/2" > 245 3/4" > 246" > 246 1/4" > 246 1/2" > 246 3/4" > 247" > 247 1/4" > 247 1/2" > 247 3/4" > 248" > 248 1/4" > 248 1/2" > 248 3/4" > 249" > 249 1/4" > 249 1/2" > 249 3/4" > 250" > 250 1/4" > 250 1/2" > 250 3/4" > 251" > 251 1/4" > 251 1/2" > 251 3/4" > 252" > 252 1/4" > 252 1/2" > 252 3/4" > 253" > 253 1/4" > 253 1/2" > 253 3/4" > 254" > 254 1/4" > 254 1/2" > 254 3/4" > 255" > 255 1/4" > 255 1/2" > 255 3/4" > 256" > 256 1/4" > 256 1/2" > 256 3/4" > 257" > 257 1/4" > 257 1/2" > 257 3/4" > 258" > 258 1/4" > 258 1/2" > 258 3/4" > 259" > 259 1/4" > 259 1/2" > 259 3/4" > 260" > 260 1/4" > 260 1/





PM-21TH

BILL OF MATERIALS



A. Parts


Part #	Description	Qty.	Picture
PM-21TH-#fbd	Driver foot bracket	1	
PM-21TH-#fbp	Passenger foot bracket	1	
2-SAB-FS-075	Partition Spacer 7.5"	2	
PM-21TH-#uwkd	Driver upper wing	1	
PM-21TH-#uwkp	Passenger upper wing	1	

PM-21TH

PM-21TH-#pbpb	Passenger b-pillar bracket	1	
PM-21TH-#dbpb	Driver b-pillar bracket	1	
PM-21TH-#lwd	Driver lower wing	1	
PM-21TH-#lwp	Passenger lower wing	1	

B. Hardware

1-FST-06-60825	¼-20 x 0.625" button head socket screw	6	
1-FST-06-60830	¼-20 x 0.750" button head socket screw	2	

1-FST-50-60800	¼ washer	14	
1-FST-35-31000	¼-20 Nylon nut	8	
2-PAR-23-4004	Vinyl caps	2	
HW-SAB-PAR14	Hardware pack	1	