



July 29, 2025

Revision A

A division of Troy Sheet Metal Works, Inc.
1024 South Vail Avenue, Montebello, CA 90640
www.troyproducts.com 323 720-4100

Part No: CP-25XP-CARGO
Description: Cargo Platform


Vehicle: Ford Expedition
Model year: 2025



Tools Required:	1/8" Allen Key	7/16" Wrench	Impact Driver	5/8" Socket	8mm Wrench
	5/32" Allen Key	1/2" Wrench	10mm Socket	14mm Socket	

Troy Products recommends reading through all installation instructions prior to installation to check all necessary parts have been included (check against bill of materials table.)

IMPORTANT NOTE: If using a Rear Partition, it should be installed prior to the Cargo Platform. Cardboard can be placed on the side of the vehicle trim to prevent scratching the trim when installing the lid.















CP-25XP-CARGO

Quick Guide

1. Remove the interior foam and plastic from vehicle saving OEM hardware.
2. If a Rear Partition is to be installed, install the Rear Partition first.
3. Attach the front legs to the vehicle floor using the OEM hardware.
4. The Passenger and Driver Rails can be installed using the provided tri-lobe bolts and remaining OEM hardware.
5. Cross supports need to be installed perpendicular to the driver and passenger rails.
6. Install the gap panel and ensure gas struts are fully tightened onto assembly.
7. The electronics tray can be installed; the wire harness will need to be unclipped and relocated in front of the tray.
8. Lastly slide the lid onto the rails, bolt down using FH socket screws and ensure locks are properly adjusted to prevent the lid from rattling.


CP-25XP-CARGO - BILL OF MATERIALS

PARTS	
Part number: CP-25XP-CARGO-#fdl Description: FRONT DRIVER LEG QTY: 1 	Part number: CP-25XP-CARGO-#fpl Description: FRONT PASSENGER LEG QTY: 1 
Part number: CP-25XP-CARGO-#dra Description: DRIVER PIVOT RAIL QTY: 1 	Part number: CP-25XP-CARGO-#pra Description: PASSENGER PIVOT RAIL QTY: 1 
Part number: CP-25XP-CARGO-#cs Description: CROSS SUPPORT QTY: 2 	Part number: CP-25XP-CARGO-#et Description: ELECTRONICS TRAY QTY: 1 
Part number: CP-25XP-CARGO-#la Description: LID ASSEMBLY QTY: 1 	Part number: CP-25XP-CARGO-#gap Description: GAP PANEL QTY: 1 
Part number: CP-25XP-CARGO-#gpbktd Description: GAP PANEL BRACKET DRIVER QTY: 1 	Part number: CP-25XP-CARGO-#gpbktp Description: GAP PANEL BRACKET PASSENGER QTY: 1 


HARDWARE	
Part number: 1-FST-35-10100 Description: ¼-20 Wing Nut QTY: 4 	Part number: 1-FST-06-60825 Description: ¼-20 x 5/8 BH SOCKET SCREW QTY: 22 
Part number: 1-FST-35-31000 Description: ¼-20 Nylock Nut QTY: 22 	Part number: 1-FST-04-65620 Description: #10-32 x .5" FH Socket Screw QTY: 8 
Part number: 1-FST-10-66321 Description: 7/16-20 x 1.125 Tri-Lobe Bolt QTY: 2 	

Installation


- 1.) The OEM interior pieces will need to be removed from the vehicle in order to install the cargo platform, OEM hardware will be reused when installing the platform. The plastic and foam pieces that need to be removed are highlighted in white below. **SAVE OEM HARDWARE**




- 2.) After removing the plastic and foam from the rear of the vehicle, install the rear partition if it is to be used with the cargo platform. OEM hardware will be reused from the previous step. The front driver and passenger legs can now be installed into the vehicle as shown below using the same OEM hardware. **DO NOT FULLY TIGHTEN AT THIS TIME**




- 3.) Once the front legs have been installed the driver and passenger rails can be installed into the vehicle, ensure that the gas struts are fully tightened onto the pivot arms before the next steps. OEM hardware will be reused for the hole closest to the back hatch door and the provided 7/16-20 tri-lobe bolts will need to be installed into the vehicle using an impact to drive bolt into the designated hole. Additionally, 1/4-20 bolts and nuts will be used to attach the rail to the legs installed in the previous step. **DO NOT FULLY TIGHTEN HARDWARE INSTALLED IN THIS STEP**




- 4.) The cross supports will need to be installed next; this is done using more of the included ¼-20 hardware to attach perpendicularly to the driver and passenger rails. **FULLY TIGHTEN ALL HARDWARE NOW**



- 5.) The gap panel will be installed next; this will slide down in between the rear partition and the cross support. Bolt the gap panel to the rear partition and the cross support using the provided ¼-20 hardware. The electronics tray can also be installed; this will be installed after the gap panel and is simply attached to the rails with the provided wing nuts for easy access. (The wiring harness will need to be unclipped on the sides and moved towards the back of the vehicle). **FULLY TIGHTEN ALL HARDWARE**



- 6.) Finally, the lid assembly can be installed on to the top of the pivot arms. Cardboard can be placed on the sides of the trim to prevent the lid from scratching the trim during the installation. The lid will be lifted onto the pivot rails and slide into place using the rails as a guide to position the lid. Install remaining #10-32 FH screws into the top of the lid. The locks will now be adjusted as needed. **FULLY TIGHTEN ALL HARDWARE**



Your installation is now complete. If you have any questions or suggestions for adding additional instructions, please call **Customer Service at (800) 700-8769**.